DIGITAL LUX METER

AL-161
AL-161I
AL-161F

This Digital Lux Meter is small in size, light in weight, easy to carry. Although complex and advanced, it is convenient to use and operate. Its ruggedness will allow many years of use if proper operating techniques are followed. Please read the following instructions carefully and always keep this manual within easy reach.

4. MEASURING CONSIDERATIONS

- 4.1 Press the Power Key or the Power/Hold Key to turn on the meter.
- 4.2 Press the Unit Conversion Key to select the proper unit.
- 4.3 Hold the sensor at the tested position, read when the displayed value is stable. To make sure the measurement is accurate, keep the light vertical to the sensor. When reading, pay attention to the Range indicator. The true value is the reading times the indicated gear.
- 4.4 When measuring, press the Power/Hold Key, 'MAX' indicator comes out, the maximum value will be held on the display.

5. CONNECT WITH THE COMPUTER

- 5.1 Using optional 'RS232C Cable' or 'Bluetooth Adapter', data transmission to PC can be realized.
- 5.2 Press the Send Key to transmit the data to

1. FEATURES

- * Wide measuring range and high resolution.
- * Digital display gives exact reading with no guessing or errors.
- * In build LOW BATTERY indicator.
- * Auto zero adjustment.
- * The use of durable, long-lasting components, including a strong, light weight ABS-plastic housing assures maintenance free performance for many years. The housing has been carefully shaped to fit comfortably in either hand.

2. GENERAL SPECIFICATIONS

Display: LCD

Parameters measured: AL (LUX)

FC (FOOT CANDLE)

Power supply 4x1.5 AAA battery

Operating condition: Temp. 0~50°C

Humidity < 80%

Size: Main Unit: 140x70x31 mm

Sensor: 96x58x16 mm

PC.

6. REPLACEMENT OF BATTERY

- the symbol shows up on the display.
- 6.2 Slide the battery cover away from the unit and remove the batteries.
- correctly into the case.
- 6.4 If the instrument is not to be used for any


Weight: about 200g including batteries

Model: all-in-one machine

3. ELECTRICAL SPECIFICATIONS

Resolution	AL-161 Range	AL-161L AL-161R Range	Accuracy
X1	0. 1~500.00Lux	0. 01~50.00Lux	± (4%n+5d)
X10	500. 00~5000Lux	50. 00~500.0Lux	± (4%n+5d)
X100	5000~200, 000Lux	500.0~200, 000Lux	± (4%n+4d)
1FC	0~20, 000FC	0~20, 000FC	± (4%n+4d)

4. SPECTRUM FOR LIGHT SENSO



5. FRONT PANEL DESCI



3 6 Power/Hold Key 3 1 Power Key

3-2 Display 3-7 Unit Conversion Key

3-3 Range Indicator 3-8 RS-232 Interface

3-4 Battery Cover 3-9 Sensor

3-5 Send Key

3

9. ADEQUATE LIGHT FOR WORK AREA

			Α	DEQU	ATE	LI	GHT LI	EVE	LS F	OR WO	RK ARI	ΞA					
LUXE	10	000 5000	300	0 200	00 1	500	1000	750	500	300	200	. 15		75	50	30	20
FACTORY	-	ELECTRONIC PARTS ASSEMBLY LINE DRAFTING		TYPE SETTI NG AT PRINTING SHOP INSPECTION WORK		VISUAL WORK AT PRODUCTION LINE		PACKING WORK		EX: ENTRAY PASS/	T ICE	INDOOR EMERGENCY STAIRS WAREHOUSE LOADING OR UNLOADING WORK					
OFFICE	TYPING DRAFT - ING				CLERICAL	WORK	CONFERENC E ROOM DINNING ROOM RECEPTION ROOM		MOO!			ENTR - ANCE WARE - HOUSE	INDOOR EMERGENCY STAIRS		·		
HOME						SE	WING		DING UDY	MAKE UP	DINNI NG TABLE	RECRE ATION AL ACTIV ITIES	WAS - HING				
STORE		FOREFRONT OF SHOW WINDOW				SHOW WINDOW PACKING TABLE	•	EL EV AT OR	DISP- LA Y STAN D	RECEP TION ROOM	CORR IDOR STAIR S	INDO	OORS				
HOSPITAL		EYE INSPE - CTION					OPERATING ROOM EMERGENCY	3		CAL EXAMINA' ROOM DINNING ROO		WAIT ING ROO M	SICK ROOM WARE HOU - SE	STAIRS	EMERGENCY STAIRS		
SCH00L							DRAFTING ROOM LIBRARY			LASS OOM		WASI	G YMNAYM H ROOM ITORIUM		EMERGENCY STAIRS		
RESTAURAN T							SHOW ROOM		R	OKING OOM NNING	ENTRAI WASH R		CORR ST/	IDOR AIRS			
BABER BEAUTY PARLOR							HAIR DYEI WAKEUP HAIR DRESSING		WAS	AVING HAIR HING SSING							

- 6.1 It is necessary to replace batteries when
- 6.3 Install the batteries (4x1.5v AAA)
- extended period, remove batteries.